

END OF FILM SENSOR

This sensor stops the machine when it runs out of film.